



# Kitchen Sink Waste Kit

IMPORTANT: If you are in any doubt, STOP and seek professional help. Do not proceed unless you are sure.

## Your kitchen sink waste kit

Your kitchen sink waste is designed for use with a rectangular overflow and a sink waste diameter of between 110 and 114mm.

## To fit your kitchen sink waste

- 1 Place the pipe nut onto the open end of the overflow pipe and then place on the conical washer so that it fully covers the end of the overflow pipe.
- 2 Insert this end of the overflow pipe into the outlet on the waste body. Ensure the conical washer seats correctly into the outlet hole and tighten the pipe nut. The overflow body should already be attached to the other end of the pipe.
- 3 Place the lower washer onto the waste body and carefully raise the whole assembly onto the underside of the sink waste hole.
- 4 On the topside of the sink waste hole, add the upper washer and waste grating. Then insert and tighten the lock bolt to secure everything together. Make sure the assembly sits centrally within the sink waste hole and use a large flat blade screwdriver to fully tighten the lock bolt - take care not to overtighten.
- 5 Ensure the rectangular washer is correctly in place on the overflow body. Position the overflow body and washer behind the overflow holes of the sink and use the supplied screw to secure it in place.
- 6 Check that the overflow pipe is not twisted or kinked and that both ends are secure.
- 7 Place the strainer plug into the waste grating. The assembly is now ready for you to attach a trap (by others) to the underside of the waste body.

